

Note: Dimensions are nominal measurements only

SPECIFICATIONS

RECOMMENDED USE

Domestic, Commercial

MATERIAL

Solid Brass

TEMPERATURE RATING

Maximum continuous working temperature 75°C
If the water temperature exceeds 75°C, an approved tempering valve must be fitted

PRESSURE RATING

Recommended minimum working pressure 150kPa
Recommended maximum working pressure 500kPa
Hot and cold water inlet pressure should be equal

BOXES IN SET


2 Boxes

INSTALLATION GUIDE


Note: This product must be installed by a licensed plumber. This is a general installation guide - there are many factors involved that can alter the installation method. **AU/NZ:** For installations within Australia and New Zealand, this product must be installed in compliance with AS/NZS 3500. **UK:** For installations in the United Kingdom this product must be installed in compliance with the Water Supply (Water Fittings) Regulations and Water Supply (Water Fittings) (Scotland) Byelaws. **Other:** For installations outside these countries, this product must be installed in compliance with the standards in your respective country.




- ① Make a hole 45mm in diameter.
Note: If cutting a stone benchtop it will need to be cut in a controlled environment by a licensed tradesperson as per OH&S regulations.




- ③ Push the flexi hoses through the hole. Fix to the bench by screwing the fixing nut and washers.





- ② 1. Remove the fixing nut and washers.
 2. Connect the flexi hoses (take note of red & blue mark)



- ④ Attach the hot/cold flexi hoses to the corresponding hot/cold water supply.
Note: Purge the lines with fresh water before connecting the flexi hoses to any spout.




- ⑤ Mixer Operation



Regularly clean with mild liquid detergent or soap and water



DO NOT use cream cleaners or bleach. These substances are abrasive



DO NOT use cleaning pads with abrasive surfaces as this may scratch the material


INSTALLATION GUIDE



Note: This product must be installed by a licensed plumber. This is a general installation guide - there are many factors involved that can alter the installation method. **AU/NZ:** For installations within Australia and New Zealand, this product must be installed in compliance with AS/NZS 3500. **UK:** For installations in the United Kingdom this product must be installed in compliance with the Water Supply (Water Fittings) Regulations and Water Supply (Water Fittings) (Scotland) Byelaws. **Other:** For installations outside these countries, this product must be installed in compliance with the standards in your respective country.


1 Mark out desired location of spout.

Cut hole using a 30mm hole saw.
 Note: If cutting a stone benchtop it will need to be cut in a controlled environment by a licensed tradesperson as per OH&S regulations.




2 Remove the spout by pushing in the plastic clip with an Allen key or screwdriver.


Caution: be careful not to scratch the spout!



3 Fix base connection to benchtop with brass nut ensuring the rubber washer and spacer are fitted to the underside of the benchtop. Use pliers to hold the base connection while nut is tightened.



4 Connect pipework to inlet of spout.




IN THE BOX		1 x spout		1 x spacer (if required)
		1 x base connection		1 x rubber washer
				1 x brass nut



Regularly clean with mild liquid detergent or soap and water



DO NOT use cream cleaners or bleach. These substances are abrasive.



DO NOT use cleaning pads with abrasive surfaces as this may scratch the material.