



## BARRE PROGRESSIVE WALL-MOUNTED SET





Note: Dimensions are nominal measurements only


SPEC	IFI	CAT	$\cap$	NS
J L C		-	$\sim$	

MATERIAL	Solid Brass
TEMPERATURE RATING	Maximum continuous working temperature 75°C If the water temperature exceeds 75°C, an approved tempering valve must be fitted
PRESSURE RATING	Recommended minimum working pressure 150kPa Recommended maximum working pressure 500kPa Hot and cold water inlet pressure should be equal
SUITABLE HOT WATER UNITS	Storage tank: Yes Continuous Flow: Yes Gravity Feed: Not suitable
STANDARDS	WELS 5 Star, 5.5L/min, T40405

PACKAGING Contains 4 boxes in this set



## IN-WALL MINIMAL MIXER BODY



**DISCLAIMER:** To achieve infiniti (interchangeable sleeves) finish wall must fall between point A and B. Please ensure waterproofing is set back from finish wall and does not obstruct sleeves.

Note: Dimensions are nominal measurements only

SPECIFICATIONS	
RECOMMENDED USE	Domestic
MATERIAL	Solid Brass
PRESSURE RATING	Recommended minimum working pressure 150kPa Recommended maximum working pressure 500kPa Hot and cold water inlet pressure should be equal
TEMPERATURE RATING	Maximum continuous working temperature 75°Clf the water temperature exceeds 75°C, an approved tempering valve must be fitted
SUITABLE HOT WATER UNITS	Storage tank: Yes Continuous Flow: Yes Gravity Feed: Not suitable

STANDARDS

AS/NZS 3718:2005, WM-022852


Note: This product must be installed by a licensed plumber. This is a general installation guide - there are many factors involved that can alter the installation method. AU/NZ: For installations within Australia and New Zealand, this product must be installed in compliance with AS/NZS 3500. UK: For installations in the United Kingdom this product must be installed in compliance with the Water Supply (Water Fittings) Regulations and Water Supply (Water Fittings) (Scotland) Byelaws. Other: For installations outside these countries, this product must be installed in compliance with the standards in your respective country.




#### **ROUGH IN**

See Specification image for finish wall setback

- Screw in-wall body into wall structure with provided screws.
- 2 Connect hot, cold and mixed lines. TEST AND CHECK FOR LEAKS.
- Sheeting and waterproof layer can now be applied.
  - \*Ensure cutout in finish wall is 47mm diameter.








#### WHAT'S IN THE BOX

- 1. Body
- 2. Fixing screws
- 3. Cartridge
- 4. Locking nut





Regularly clean with mild liquid detergent or soap and water




DO NOT use cream cleaners or bleach.
These substances are abrasive




DO NOT use cleaning pads with abrasive surfaces as this may scratch the material



## BARRE PROGRESSIVE HANDLE KIT





Front View Side View

Note: Dimensions are nominal measurements only

SPECIFICATIONS	
RECOMMENDED USE	Domestic
MATERIAL	Solid Brass

Note: This product must be installed by a licensed plumber. This is a general installation guide - there are many factors involved that can alter the installation method. AU/NZ: For installations within Australia and New Zealand, this product must be installed in compliance with AS/NZS 3500. UK: For installations in the United Kingdom this product must be installed in compliance with the Water Supply (Water Fittings) Regulations and Water Supply (Water Fittings) (Scotland) Byelaws. Other: For installations outside these countries, this product must be installed in compliance with the standards in your respective country.



NOTE: See Progressive Mixer Body installation guide for In-Wall set out.


- Choose sleeve based on how far your
  - In-wall protrudes from finish wall and slide on.





Slide back plate on. Screw dome on.




Tighten grub screw with allen key. Replace grub screw cap.








#### MIXER OPERATION



#### WHAT'S IN THE BOX

- 1. Back plate
- 2. Long sleeve
- 3. Dome
- 4. Handle
- 5. Grub screw
- 6. Short sleeve
- 7. Allen key





Regularly clean with mild liquid detergent or soap and water




DO NOT use cream cleaners or bleach. These substances are abrasive




DO NOT use cleaning pads with abrasive surfaces as this may scratch the material



# ROUNDED RECTANGLE MIXER & SPOUT BACKPLATE



Section View A-A



Front View


Note: Dimensions are nominal measurements only

#### **SPECIFICATIONS**

**RECOMMENDED USE** 

Domestic


Note: This product must be installed by a licensed tradesperson. This is a general installation guide - there are many factors that are involved that can alter the installation method.





# WALL-MOUNTED SPOUT






Note: Dimensions are nominal measurements only


SPECIFICATIONS		
RECOMMENDED USE	Domestic	
MATERIAL	Solid Brass	
TEMPERATURE RATING	Maximum continuous working temperature 75°C If the water temperature exceeds 75°C,an approved tempering valve must be fitted	
PRESSURE RATING	Recommended minimum working pressure 150kPa Recommended maximum working pressure 500kPa Hot and cold water inlet pressure should be equal	
SUITABLE HOT WATER UNITS	Storage tank: Yes Continuous Flow: Yes Gravity Feed: Not suitable	
STANDARDS	WELS 5 Star, 5.5L/min, T36442	

This product must be installed by a licensed plumber. This is a general installation guide - there are many factors that are involved that can alter the installation method. This product install must comply with AS/NZS 3500.



- Slide the back plate onto the spout, make sure that the rubber is firmly in place to protect the spout and stop the back plate from moving around.
- Apply teflon thread tape to the breech point, twist the spout on and hand tighten.







Regularly clean with mild

liquid detergent or soap

and water



DO NOT use cream cleaners or bleach. These substances are abrasive



DO NOT use cleaning pads with abrasive surfaces as this may scratch the material